

Instruction Sheet



Cat.-No.: 703-080-G15

TEK-CHECK™ R134A Gas Source

The TEK-Check is a refrigerant (R134a) gas source used to test INFICON leak detectors for proper operation. It leaks at approximately 5 to 9 g/a and will last approximately one year.

How To Use The TEK-Check

1. Remove the square-shaped vinyl cover of the TEK-Check can.
2. Turn on the leak detector, and set it at its HIGH sensitivity.
3. Move the leak detector probe close to the top of the TEK-Check can.
4. When operating properly, the detector will indicate a leak. If it does not:
 - 4a. Ensure that the leak detector is set at HIGH sensitivity.
 - 4b. Ensure that the TEK-Check is not empty by shaking the can to feel the presence of liquid inside.
 - 4c. Replace the sensor in the leak detector.
 - 4d. If the leak detector still does not indicate a leak, take the detector to your wholesaler for warranty evaluation.
5. Replace the vinyl cover to extend the useful life of the TEK-Check.

Warning

Do not expose the TEK-Check to temperatures exceeding 120°F (50°C).

Warning

Do not disassemble the TEK-Check.

Warning

Do not inhale the R134a gas.

TEK-CHECK™ R134A 冷媒ガス

TEK-Check はインフィコン社のリークディテクターが正常に

作動するかを検査する R 1 3 4 a 冷媒ガスです。漏れ量は約 5 - 9 g / 年で使用期間は約 1 年間です。

TEK-Check の使用方法

1. TEK-Check 本体上部からキャップを外します。
2. リークディテクターの電源を入れ、感度スイッチを「H i g h」にします。
3. プローブを TEK-Check の上部に近づけます。
4. 正常に作動した場合、リークディテクターはガス漏れを検知します。作動しない場合は、
 - 4a. 感度スイッチが「H i g h」になっているかを確認して下さい。
 - 4b. TEK-Check を振り、液体ガスが入っているか確認して下さい。
 - 4c. リークディテクターのセンサーを交換して下さい。
 - 4d. 上の 3 項目を試しても作動しない場合は、保証対象となるか製品を購入された販売代理店にご確認ください。
5. TEK-Check を有効にご利用いただけるよう、ご使用後は、ビニールキャップをはめてください。

警告

TEK-Check は 5 0 °C を越える場所に放置しないでください。

警告

TEK-Check を解体しないでください。

警告

R 1 3 4 a 冷媒ガスを吸い込まないでください。